



How to Verify the Warranty Status of a VST Component

1. Go to www.vstthose.com
Click "Customer Support"
Select "Product Warranty"



2. Click the "Serial # Search" link.



3. Enter the serial number and click "Search."



4. Review the warranty status of the component



Product Bulletin

Online Warranty Verification

10.21.09



Vapor Systems Technologies, Inc.

650 Pleasant Valley Drive

Springboro, Ohio 45066 (USA)

Toll Free: 1-888-878-4673

Phone: 937-704-9333

Fax: 937-704-9443

www.vstthose.com

- To check another number, delete the last number you checked and enter the new number you want to check.

Click Search



- To exit, close the window.

