

8.8 Data Storage Alarm

- The GREEN MACHINE will operate when there is a Data Storage Alarm, but the card will not or cannot record the data.
- The Data Storage Alarm will activate when the following items occur:
 1. A digital storage drive is not installed in the PLC slot.
 2. When the digital storage drive is not inserted into the slot properly.
- Correct the above problem(s) and the Data Storage Alarm will clear.